




Instrukcja montażu i obsługi DFM

Lindenstraße 20, DE-74363 Güglingen, Telefon: +49(0)7135-102-0, Telefax: +49(0)7135-102-147, E-Mail: info@afiso.de, Internet: www.afiso.de









A

DFM	DN	G x G	L(mm)
10-1M	10	G $\frac{3}{4}$ x G $\frac{3}{4}$	67
15-1M	15	G1 x G $\frac{3}{4}$	87
15-1M	15	G1 x G1	87
15-1M	15	G1 $\frac{1}{2}$ x G $\frac{3}{4}$	87
15-1M	15	G1 $\frac{1}{2}$ x G1	87
15-2M	15	G $\frac{3}{4}$ x G $\frac{3}{4}$	107
15-2M	15	G1 x G1	107
20-2M	20	G1 $\frac{1}{4}$ x G1 $\frac{1}{4}$	133
20-2M	20	G1 $\frac{1}{2}$ x G1 $\frac{1}{2}$	133

100°C (10-1M)
120°C
10 bar


B

DFM	DN	G x G	L(mm)
15-2M	15	G $\frac{3}{4}$ x G $\frac{3}{4}$	106
15-2M	15	G1 x G1	102
20-2M	20	G1 x G1	131
20-2M	20	G1 $\frac{1}{4}$ x G1 $\frac{1}{4}$	129
20-2M	20	G1 $\frac{1}{2}$ x G1 $\frac{1}{2}$	129


C

DFM	DN	G x G	L(mm)
15-4M	15	G $\frac{3}{4}$ x G1 $\frac{1}{2}$	137
15-4M	15	G1 x G1 $\frac{1}{2}$	137


DFM 15-4M



DFM 15-2M
DFM 20-2M



1



2



3



4 **DFM 15-2M**
DFM 20-2M

